



# SERVICE INSTRUCTIONS

SVC-5100-109

## AirDrive Trolley™ Control Panel Membrane Touch Pad Kit

### PURPOSE

Replace the control panel membrane touch pad in the AirDrive Trolley.

### WARNING STATEMENTS

**! WARNING ! RECOMMENDED MAINTENANCE AND SERVICE, AS WELL AS USE OF ONLY QFIX-PROVIDED ACCESSORIES, COMPONENTS, AND REPLACEMENT PARTS, ARE NECESSARY TO ENSURE THE SAFETY, PERFORMANCE, AND MRI COMPATIBILITY OF THE PRODUCT(S), AS WELL AS TO MAINTAIN APPLICABLE WARRANTIES.**

**! WARNING ! ALL MAINTENANCE AND SERVICE PERFORMED ON THE AIRDRIVE™ SYSTEM, AIRSHUTTLE™ DEVICES, AND ALL ACCESSORIES SHOULD BE CONDUCTED OUTSIDE MRI ENVIRONMENTS.**

### DIRECTIONS

Contact Qfix for instructions on installation.

### ESTIMATED TIME TO COMPLETE

30–60 minutes hands on to replace the control panel membrane touch pad on AirDrive Trolley.

## KIT CONTENTS

Part Number	Quantity	Part Name
2005425	1	Transport Membrane Touch Pad

## REQUIRED TOOLS

- Isopropyl Alcohol (or equivalent cleaning solvent)
- Gloves and Rags
- Flat blade or scraping tool



440 Church Road  
Avondale, PA 19311 USA  
[www.Qfix.com](http://www.Qfix.com)

+1 484.720.6053 / 800.526.5247

+1 610.268.0588 / 800.831.8174

[sales@Qfix.com](mailto:sales@Qfix.com)

AirDrive, AirDrive Trolley, and AirShuttle are  
trademarks of Qfix.

2008149\_EN\_B  
2022-01