



SERVICE INSTRUCTIONS

SVC-5100-111

AirDrive™ Blower Membrane Touch Pad Kit

PURPOSE

Replace blower membrane touch pad components in the AirDrive Caddie™ and AirDrive Trolley™.

WARNING STATEMENTS

! WARNING ! RECOMMENDED MAINTENANCE AND SERVICE, AS WELL AS USE OF ONLY QFIX-PROVIDED ACCESSORIES, COMPONENTS, AND REPLACEMENT PARTS, ARE NECESSARY TO ENSURE THE SAFETY, PERFORMANCE, AND MRI COMPATIBILITY OF THE PRODUCT(S), AS WELL AS TO MAINTAIN APPLICABLE WARRANTIES.

! WARNING ! ALL MAINTENANCE AND SERVICE PERFORMED ON THE AIRDRIVE SYSTEM, AIRSHUTTLE™ DEVICES, AND ALL ACCESSORIES SHOULD BE CONDUCTED OUTSIDE MRI ENVIRONMENTS.

DIRECTIONS

Contact Qfix for instructions on installation.

ESTIMATED TIME TO COMPLETE

30–60 minutes hands on to replace blower membrane touch pads on AirDrive Caddie and AirDrive Trolley.

KIT CONTENTS

Part Number	Quantity	Part Name
2006627	4	Transport Blower Membrane Touch Pad

REQUIRED TOOLS

- Isopropyl Alcohol (or equivalent cleaning solvent)
- Gloves and rags
- Flat blade or scraping tool



440 Church Road
Avondale, PA 19311 USA
www.Qfix.com

+1 484.720.6053 / 800.526.5247

+1 610.268.0588 / 800.831.8174

sales@Qfix.com

AirDrive, AirDrive Caddie, AirDrive Trolley, and
AirShuttle are trademarks of Qfix.

2008607_EN_B
2022-01