Breastboard Replacement Kit

INSTRUCTIONS FOR USE (IFU)

CQ MEDICAL™

MT-350-N LEG FORK REPLACEMENT

NOTE: Tools Required:

- 5/64" Allen Wrench *(not provided)*
- 1/8" Allen Wrench *(not provided)*
- Adhesive *(provided)*
- Wire ties (2) *(provided)*

REMOVAL FOR STYLE 1 AND STYLE 3:

1. Squeeze sliding cross-bar towards stationary cross-bar to secure spring during disassembly.

NOTE: Wire tie cross-bars together to aid in disassembly.



I. Stationary Cross-bar
II. Sliding Cross-bar

2. Remove and discard remaining screws (2) and old retaining clip.



I. Leg Fork
II. Retaining Clip

3. Remove and discard remaining screw and old leg fork.



REMOVAL FOR STYLE 2:

1. Remove set screw from bottom side of leg fork.



2. Squeeze sliding cross-bar towards stationary cross-bar to secure spring during disassembly.

NOTE: Wire tie cross-bars together to aid in disassembly.



I. Stationary Cross-bar
II. Sliding Cross-bar

3. Remove and discard remaining screws (3) and old leg fork.



REMOVAL FOR STYLE 4:

1. Squeeze sliding cross-bar towards stationary cross-bar to secure spring during disassembly.

NOTE: Wire tie cross-bars together to aid in disassembly.



I. Stationary Cross-bar
II. Sliding Cross-bar

2. Remove and discard remaining screws (4) and old leg fork.



REPLACEMENT FOR STYLE 1 (PRE 2007):

1. Insert screws (2) through aligned retaining clip and leg fork into sliding cross-bar.

NOTE: Ensure stationary cross-bar is inserted into slot of leg fork during assembly.



I. Stationary Cross-bar
II. Leg Fork
III. Retaining Clip
IV. Sliding Cross-bar
V. Lower Leg

2. Apply minimum amount of adhesive onto new shoulder screw threads. Insert through lower leg into new leg fork and tighten until light resistance is felt. Do not overtighten.



3. Wait a minimum of 15 minutes before proceeding to next step.
4. Repeat steps for opposite side of breastboard. Remove wire ties.
5. Let assembly sit for 15 minutes to ensure adhesive is set. Ensure leg assembly rotates as expected.

REPLACEMENT FOR STYLE 1 (POST 2007), STYLE 2, STYLE 3 AND STYLE 4:

1. Insert screws (2) through aligned retaining clip and leg fork into sliding cross-bar.

NOTE: Ensure stationary cross-bar is inserted into slot of leg fork during assembly.



I. Stationary Cross-bar
II. Leg Fork
III. Locking Tab
IV. Retaining Clip
V. Long Screw
VI. Short Screw
VII. Sliding Cross-bar
VIII. Lower Leg

2. Apply minimum amount of adhesive onto new shoulder screw threads. Insert through lower leg into new leg fork and tighten until light resistance is felt. Do not overtighten.



3. Wait a minimum of 15 minutes before proceeding to next step.
4. Repeat steps for opposite side of breastboard. Remove wire ties.
5. Let assembly sit for 15 minutes to ensure adhesive is set. Ensure leg assembly rotates as expected.

Qfix
440 Church Rd
Avondale, PA 19311
United States
800.842.8688, +1 712.737.8688
info@cqmedical.com

COPYRIGHT © 2026 ALL RIGHTS RESERVED. CQ MEDICAL IS A TRADEMARK OF MEDTEC LLC. ALL OTHER TRADEMARKS ARE PROPERTY OF THEIR RESPECTIVE OWNERS. PRINTED IN USA.

www.CQmedical.com

2026.02.02

143-206_2